

GOLDAIR

Operating Instructions

800W Juicer



Models: GJE300G, GJE300R

General care and safety guide

Thank you for choosing this GOLDAIR Juicer. This GOLDAIR appliance has been designed and manufactured to high standards of engineering and with proper use and care, as described in this leaflet, will give you years of useful service. Please read these instructions carefully and keep them for future reference.

ALWAYS

- ✓ Always ensure hands are dry before handling the plug or switching on the Juicer.
- ✓ Always use the Juicer on a secure, dry, level surface.
- ✓ Always disconnect the Juicer from the supply if it is left unattended and before assembling, disassembling or cleaning.
- ✓ Carry out regular checks of the supply cord to ensure no damage is evident.
- ✓ Return the Juicer after a malfunction, or if it has been damaged in any manner, to an authorised electrical service technician for examination, repair or adjustment as special purpose tools are required.
- ✓ Children should be supervised to ensure that they do not play with the appliance.
- ✓ Take care when handling the sharp cutting blades while emptying the bowl and during cleaning.
- ✓ Switch off the appliance and disconnect from supply before cleaning, changing accessories or approaching that move in use.
- ✓ Avoid contact with the moving parts. Keep hands, hair, clothing, as well as spatulas and other utensils away from blades of the Juicer during operation to reduce the risk of injury to person and/or damage to the Juicer.
- ✓ If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- ✓ Ensure that the area around the Juicer is clear from other liquids during use, as this may leak into the Juicer during operation and cause a motor malfunction.

NEVER


- ✗ Never use this appliance outdoors.
- ✗ Never use this appliance for any purpose other than its intended use. This appliance is for household use only or in similar applications such as:
 - Staff kitchen areas in shops, offices and other working environments;
 - Farm houses
 - By clients in hotels, motels and other residential type environments;
 - Bed and breakfast type environments
- ✗ This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities or lack of experience and knowledge, unless they are supervised or have been given instruction concerning the use of the Juicer by a person responsible for their safety.
- ✗ Never place this appliance on or near a hot gas or electric burner or where it could touch a heated oven or microwave oven.
- ✗ Never use harsh, abrasive or caustic cleaners to clean this appliance.
- ✗ Never operate the appliance with a damaged cord or plug, after it malfunctions, or if it has been damaged in any manner.
- ✗ The Juicer is not intended to be operated by means of an external timer or separate remote-control system.
- ✗ Never use the appliance if the rotating sieve is damaged

TECHNICAL SPECIFICATION

Model No:	GJE300G, GJE300R
Power Supply:	220 - 240VAC 50Hz
Power:	800W

Components

1. Pushing bar
2. Transparent cover
3. Juicing net/filter basket
4. Middle ring
5. Safety locking handle
6. Pulp container
7. Main machine
8. Juicer jug



Cleaning

Ensure the juicer's control switch is set to the 0 (OFF) position, the power supply is turned off at the outlet and the juicer is unplugged.

Disassemble all parts (see above diagram for correct disassembly order) and wash in warm soapy water and dry thoroughly.

NOTE THAT PARTS ARE NOT DISHWASHER SAFE

Ensure all pulp is removed from the juicer blade.

CAUTION: BE CAREFUL WHEN CLEANING OR HANDLING THE JUICER FILTER BASKET AS THE BLADES ARE VERY SHARP.

The main body cannot be cleaned with water, wipe clean with a damp cloth.

The juicer blade should be cleaned carefully after each use.

Store the juicer in a dry ventilated place if it is not going to be used for a long period of time.

In order to avoid the motor becoming blocked, please clean the waste container and any residue left in the juicer chute/lid if operating the juicer frequently within a short period of time.

Before first use

Before first use

Carefully unpack the Juicer and remove all packaging material.

Clean the various Juicer accessories in warm soapy water. Rinse and dry thoroughly before use.

Operating your Juicer

1. Ensure the juicer is turned off.
2. Plug the unit into a 220-240V power outlet and turn the power on at the power outlet.
3. Clean fruit and vegetables thoroughly, ready for juicing.
4. If juicing fruit with stones or hard seeds, pit the fruit. Remove any hard inedible skins, i.e. skin of melons, pineapples and mangoes prior to juicing. If citrus fruits are being used, remove the skin prior to juicing.
5. If pieces of fruit or vegetables are very large, chop them to a size that will fit down the juicer's food chute.
6. Turn the speed control switch to the desired speed setting. Setting 1 is LOW and Setting 2 is HIGH. The lower speed setting is better for soft fruits and vegetables, while the higher speed setting is better for hard fruits and vegetables.
7. Ensure the safety catch is locked in position -vertically on top of the juicer lid.
8. Press the food pusher slowly down until all fruit or vegetables have gone through the juicer. Do not press the food pusher rapidly as the juicer will not be as effective.
9. **CAUTION: DO NOT PUT YOUR HAND OR ANY OTHER OBJECT IN THE FOOD CHUTE DURING OPERATION.**
10. The juice from the fruit and/or vegetables will flow directly into the jug and the pulp will be collected in the pulp bin.
11. **IMPORTANT: WHILE JUICING, ENSURE THE PULP BIN DOES NOT OVERFILL AS THIS CAN CAUSE DAMAGE TO THE JUICER AND PREVENT IT FUNCTIONING CORRECTLY.**
12. **DO NOT OPERATE JUICER FOR MORE THAN 30 SECONDS AT A TIME**
13. When juicing is complete, ensure that the juicer's control switch is set to the 0 (OFF) position, the power is turned off at the outlet and the juicer is unplugged.
14. It is now safe to disassemble the unit.
15. Disassemble Juicer in the following order
 - Remove pushing bar
 - Remove transparent cover
 - Remove juicing net
 - Remove middle ring
 - Remove pulp container

Recipes

Apple, Carrot & Ginger Juice

3 green apples
3 carrots, greens removed
2cm piece of fresh ginger
Process the ingredients in juicer and serve.

Blueberry Grape Juice

A handful of grapes
1 cup of blueberries, fresh or thawed from frozen
1 peeled grapefruit (optional)
Process the fruit in juicer and serve.

Apple Kiwifruit Juice

3 kiwifruit, peeled
2 apples
Process the fruit in juicer and serve.

Pineapple Orange & Strawberry Cocktail

2 peeled oranges
1 cup of fresh, cubed pineapple, skin removed
6 strawberries
Process the fruit in juicer and serve.

Cucumber & Celery Cooler

3 carrots, greens removed
1/4 medium cucumber, peeled
1 stalk celery, cut into 5cm pieces.
1 apple
1/2 lemon, peeled (optional)
Process the ingredients in juicer and serve.

Calcium Drink

4 carrots, greens removed
1/2 cup of fresh broccoli pieces
2 apples
A small handful of fresh parsley
1/2 lemon, peeled (optional)
Process the ingredients in juicer and serve.

Fruit Punch

6 strawberries, fresh or thawed
1 apple
1/2 peeled orange
Process the fruit in juicer and serve.

Potassium Drink

4 medium carrots, greens removed
1 apple
1 stalk of celery, cut into 5cm pieces
A small handful of fresh parsley
A small handful of fresh spinach
1/2 lemon, peeled (optional)
Process the ingredients in juicer and serve.

Ginger Ale with Lemon & Lime

A handful of grapes
2 apples
2cm piece of fresh ginger
1/2 lime
1/4 lemon
sparkling mineral water
Remove the grapes from the stem.
Juice the apple and ginger together, then juice the rest of the fruit.
Pour the juice in a large glass, fill to the top with sparkling water and serve with ice.

Sparkling Juice

2 kiwifruit
1 peeled orange
1/2 mango, skin removed.
sparkling mineral water
Process the fruit in a juicer. Pour the juice in a large glass and fill to the top with sparkling water and serve.

Apple Cider with Ginger

2cm piece of ginger
3 apples
Process in juicer and serve.

Peach Pear & Apple Juice

1 apple
2 pitted peaches
1 pear
Process in juicer and serve.

GOLDAIR

SUPPORT AND TECHNICAL ADVICE

Goldair – New Zealand

Monday – Friday 8am-5pm
Phone +64 (0)9 917 4000
Phone 0800 232 633
info@cdb.co.nz

Goldair – Australia

Monday – Friday 8am-5pm
Phone +61 (0)3 9336 4423
Phone 1300 465 324
info@cdbgoldair.com.au

GOLDAIR

Two year warranty

Thank you for purchasing this Goldair product. Your product is warranted against faults and manufacture when used in normal domestic use for a period of **two years**. In non-domestic use Goldair limits the voluntary warranty to **three months**.

Goldair undertake to repair or replace this product at no charge if found to be defective due to a manufacturing fault during the warranty period.

This warranty excludes damage caused by misuse, neglect, shipping accident, incorrect installation, or work carried out by anyone other than a qualified electrical service technician.

PLEASE KEEP YOUR RECEIPT AS THIS WILL HELP VERIFY YOUR WARRANTY.

The benefits given to you by this warranty are in addition to other rights and remedies available to you under law in relation to the goods or services to which this warranty relates.

In Australia, our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

In New Zealand this warranty is additional to the conditions and guarantees of the Consumers Guarantee Act (1993).

Goldair – New Zealand

CDB Goldair
PO Box 100-707
N.S.M.C
Auckland

Phone +64 (0)9 917 4000
Phone 0800 232 633
www.goldair.co.nz

Goldair – Australia

CDB Goldair Australia Pty
PO Box 574
South Morang
Victoria, 3752

Phone +61 (0)3 9336 4423
Phone 1300 GOLDAIR (1300 465 324)
www.goldair.com.au

IMPORTANT: Please complete and retain this warranty card



Name Purchased from

Address Date of purchase

..... Name of product

Suburb Model no

Attach a copy of the purchase receipt to this warranty card